

KUROBOX/PRO Product Specifications

Product name: KUROBOX/PRO

1. Contents

1. Contents	2
2. Product Overview.....	4
3. Special Features	4
4. Individual Specifications.....	5
5. HW Specifications	7
5.1. HW Block Diagram.....	7
5.1.1. Function Block Diagram.....	7
5.1.2 Power Block Diagram	9
5.2. External Appearance	11
5.3. Switches	12
5.3.1. Power Switch	12
5.3.2. Initialize Switch	12
5.4. Ports	13
5.4.1. Ethernet Ports	13
5.4.2. USB Ports.....	14
5.4.3. I2C Port (CN2).....	14
5.4.4. GPIO Port (CN7).....	15
5.4.5. UART Port (CN6)	15
5.5. Power Supply Specifications.....	16
5.5.1. Power Mode	16
6. Software Specifications.....	17
6.1. Main Software Versions.....	17
7. Setup Procedure	20
7.1. Flow of Operation for First Startup.....	20
7.2 Finding the IP Address.....	20
7.3. Setting the Shared Folder.....	22
8. Others	24
8.1. Factory Settings (Not Setup Condition).....	24
8.2. Error Code List.....	24
Appendix.....	25
Appendix A: Example of u-boot environment variable settings.....	25
A.1. Boot settings when uImage(nand /dev/mtdblock1), rootfs(nand /dev/mtdblock2)	25
A.2. Boot settings when uImage(nand /dev/mtdblock1), rootfs(/dev/sda2).....	25
A.3. Boot settings when uImage(/dev/sda1), rootfs(/dev/sda2)	26
A.4. Boot settings when uImage(tftp load), rootfs(nand /dev/mtdblock2)	26
A.5. Boot settings when uImage(tftp load), initrd(tftp load).....	27
Appendix B: Constructing the Development Environment	28

	3
Appendix C: Kernel Compile Procedure	31
C.1. Constructing a Cross Compile Environment	31
C.2. Compiling the Kernel	31
Appendix D: Operation check completed PCIe card	32

2. Product Overview

The Kurobox pro is a Linux-Box self-work kit that enables access from multiple PCs connected to a LAN, and is equipped with 1 10/100/1000Mbps Ethernet port and 2 USB2.0 A connectors.

3. Special Features

- GigaBit Ethernet is supported.
- Auto MDIX is supported.
- Equipped with 2 USB 2.0 ports
- System temperature and fan revolutions can be obtained via the microcomputer. Also, fan revolutions can be controlled as desired.
(However, this requires creation of the application by the user.)
- The following can be performed easily by removing the front panel.
 - (a.) UART can be accessed.
 - (b.) PCI-Express x1 can be used.
 - (c.) SATA ports for extension can be accessed.
 - (d.) I2C can be accessed.
 - (e.) Microcomputer port can be accessed.
 - (f.) GPIO can be accessed.
- you can create a spindle-less NAS by connecting a USB silicone disc and 2.5 inch SATA Flash and configuring shared settings.

If you want to enjoy hacking this product, please do not read this product specification document.

4. Individual Specifications

Item	Details
<Control Section>	
CPU	Marvell 88F5182 (400MHz)
Memory	128MB (32Mbits x 16bit x 2)
Data Storage	NOR Flash 256KiB – Buswidth 8bit(for storing u-boot) NAND Flash 256MiB – Buswidth 8bit(for rootfs)
Interface	
<Network Interface Section>	
Interface	(10BASE-T)IEEE802.3 (100BASE-TX)IEEE802.3u Conforms to (1000BASE-T)IEEE802.3ab
Type of Connector	RJ-45 Type 8 pole connector (NIC Mode) x1
Schematic Diagram	Fig. 5.4.1
Transmission Channel Coding Method	(10BASE-T) Manchester Coding (100BASE-TX) 4B5B + MLT-3 (1000BASE-T) 8B1Q4 + PAM5
Access Method	CSMA/CD
Transmission Rate	(Auto sense, auto MDIX) 10Mbps HDX/FDX 100Mbps HDX/FDX 1000Mbps FDX
Type of Cable	(10BASE-T) category 3,4,5 2-pair or 4-pair UTP cable (100BASE-TX) category 5 2-pair or 4-pair UTP cable (1000BASE-T) Enhanced category 5 4-pair UTP cable
<SATA Interface section>	
Interface	Complies with SATA1.0
Data Transmission Speed	Maximum transmission speed 3 Gbps
<HDD>	
Unit	None (3.5inch SATA HDD can be installed)
<USB Interface section>	
Interface	USB2.0/1.1
Data Transmission Speed	480Mbps
Type of Connector	Series A Rear x2
<LED Section>	
PowerLED	Green


LINK/ACT LED	Green
INFORMATION	Yellow
ERROR	Red
<Other I/F>	
SATA (Front)	x1 (CN1)
I2C	x1 (CN2)
PCI Express x1	x1 (CN5)
UART	x1 (CN6)
GPIO(09, 10)	x1 (CN7)
Microcomputer port	x1 (SW3)

5. HW Specifications


5.1. HW Block Diagram

5.1.1. Function Block Diagram

Main Board





Sub Board




5.1. 2 Power Block Diagram

Main Board



Sub Board

5.2. External Appearance
3-Side Expanded Diagram



5.3. Switches

5.3.1. Power Switch

Outline	Software switch for switching the power on/off
Method for switching power ON	<ul style="list-style-type: none"> Connect the power cable correctly, and hold down the power switch for 0.3 seconds when the power is OFF to start-up the system
Method for forcing power OFF	<ul style="list-style-type: none"> When the power is on (possible even if the system is not started), hold down the switch for 9 seconds to force the power to switch OFF

5.3.2. Initialize Switch

Outline	<ul style="list-style-type: none"> Switch for initializing the HDD
Method for initializing the HDD	<ul style="list-style-type: none"> After the system has started normally, hold down the initialize switch for 5 seconds to initialize and mount the internal HDD.
Notes	<ul style="list-style-type: none"> If the internal HDD (/dev/sda) is already formatted in xfs format, formatting will not be performed. However, if you set force_format=yes in /etc/melco/info, you can format irrespective of whether the HDD is currently formatted in xfs format or not. If the internal HDD (/dev/sda) already has partitions, those partitions will be deleted. You can easily NAS-ize a usb-disk by connecting a usb-disk when the internal HDD is not connected, and performing the operation described above. (However, caution is required as the usb-disk will be formatted in xfs format, irrespective of the usb-disk format.)

5.4. Ports

5.4.1. Ethernet Ports

No. of Ports	1 port on back of product
Type of Connector	Fig. 5.4.1

- Connector connection 1000BASE-T

Pin Number	Signal	Signal Function
1	DA+	Data A(+)
2	DA-	Data A(-)
3	DB+	Data B(+)
4	DC+	Data C(+)
5	DC-	Data C(-)
6	DB-	Data B(-)
7	DD+	Data D(+)
8	DD-	Data D(-)

- Connector connection 10BASE-T/100BASE-TX

Pin Number	Signal	Signal Function
1	TD+	Transmit data (+)
2	TD-	Transmit data (-)
3	RD+	Receive data (+)
4	(Not Use)	Not use
5	(Not Use)	Not use
6	RD-	Receive data (-)
7	(Not Use)	Not use
8	(Not Use)	Not use




Fig. 5.4.1

Ethernet Port Pin Arrangement (from cross sectional view)

Network Specifications

Physical Layer	
Supported Link Speeds	10Mbps(HALF/FULL) (10BASE-T IEEE802.3) 100Mbps(HALF/FULL) (100BASE-TX IEEE802.3u) 1000Mbps (FULL)(1000BASE-Tconforms to IEEE802.3ab)
AutoNegotiaion	Supported (Link speed decided automatically)
Auto MDIX	Supported (cross/straight detected automatically)

5.4.2. USB Ports

Number of Ports	2 port on back of product
Connectable Devices	USB 2.0 compatible devices
Type of Connector	Series A (Refer to figure 9-2 for pin arrangement)

- Connector Connection

Pin Number	Signal	Signal Function
1	Vbus	5V Power supply
2	D-	Data (-)
3	D+	Data (+)
4	GND	Earth




Fig. 5.4.2

USB connector - Pin Arrangement
(from cross sectional view)

5.4.3. I2C Port (CN2)

Number of Ports	1 port on sub board
Type of Connector	Serial pin header (4 pin)

- Connector Connection

Pin Number	Signal	Signal Function
1	SCK	Clock
2	SDA	Data
3	VCC	3.3V Power supply
4	GND	Earth

5.4.4. GPIO Port (CN7)

Number of Ports	1 port on sub board
Type of Connector	Serial pin header (4 pin)

- Connector Connection

Pin Number	Signal	Signal Function
1	IO(09)	GPIO9
2	IO(10)	GPIO10
3	VCC	3.3V Power supply
4	GND	Earth

5.4.5. UART Port (CN6)

Number of Ports	1 port on sub board
Type of Connector	Serial pin header (4 pin)

- Connector Connection

Pin Number	Signal	Signal Function
1	TXD	Transmit
2	RXD	Receive
3	VCC	3.3V Power supply
4	GND	Earth

5.5. Power Supply Specifications

Input Rating	100-220[V] (50Hz/60Hz)
Rated Output	12 [V] 5 [V]
UPS Compatibility	Compatible with the rectangular wave type output that is output when a commercial power type UPS etc is on battery backup (15 minutes)
UL Information	

5.5.1. Power Mode

Outline	This product has 2 conditions, power ON and power OFF
Power OFF	When the power supply is off to devices other than the microcomputer and RTC
Power ON	When all of the power is ON

6. Software Specifications

6.1. Main Software Versions

Kernel Version	2.6.12.6
gcc version	3.4.4 (CodeSourcery ARM 2005q3-2)
glibc	<p>2.3.6</p> <p>However, only the following libraries are installed.</p> <p>ld-2.3.6.so</p> <p>libBrokenLocale-2.3.6.so</p> <p>libSegFault.so</p> <p>libanl-2.3.6.so</p> <p>libc-2.3.6.so</p> <p>libcidn-2.3.6.so</p> <p>libcrypt-2.3.6.so</p> <p>libdl-2.3.6.so</p> <p>libm-2.3.6.so</p> <p>libnsl-2.3.6.so</p> <p>libnss_compat-2.3.6.so</p> <p>libnss_dns-2.3.6.so</p> <p>libnss_files-2.3.6.so</p> <p>libnss_hesiod-2.3.6.so</p> <p>libnss_nis-2.3.6.so</p> <p>libnss_nisplus-2.3.6.so</p> <p>libpthread-2.3.6.so</p> <p>libresolv-2.3.6.so</p> <p>librt-2.3.6.so</p> <p>libutil-2.3.6.so</p>
busybox	<p>1.4.1</p> <p>The following applets are enabled.</p> <ul style="list-style-type: none"> • archival utilities ar, bunzip2, cpio, gunzip, gzip, rpm2cpio, rpm, tar, uncompress, unlzma, unzip • coreutils basename, cal, cat, catv, chgrp, chmod, chown, chroot, cksum, cmp, comm, cp, cut, date, dd, df, diff, dirname, dos2unix, du, echo, env, expr, false, fold, head, hostid, id, install, length, ln, logname, ls, md5sum, mkdir, mkfifo, mknod, mv, nice, nohup od, printenv, printf, pwd, realpath, rm, rmdir, seq, sha1sum sleep, sort, stat, stty, sum, sync, tail, tee, test, touch, tr,

	<p>true, tty, uname, uniq, usleep, uudecode, uuencode, watch, wc, who, whoami, yes</p> <ul style="list-style-type: none"> • console utilities chvt, clear, dealloct, dumpkmap, loadfont, loadkmap, openvt reset, resize, setconsole, setkeycodes, setlogcons • debian utilities mktemp, pipe_progress, readlink, run_prtrs, start_stop_daemon, which • editors awk, ed, patch, sed, vi • finding utilities find, grep, xargs • init utilities init, reboot, halt • login/password management utilities addgroup, delgroup, adduser, deluser, getty, login, passwd, su sulogin, vlock • ext2 fs progs chattr, fsck, lsattr • linux module utilities insmod, rmmod, modprobe • linux system utilities dmesg, fbset, fdflush, fdformat, fdisk, freeramdisk, fsck.minix mkfs.minix • minix filesystem support getopt, exdump, hwclock, ipcrm, ipcs, losetup, mdev, mkswap more, mount, pivot_root, rdate, readprofile, setarch, swaponoff switch_root, umount • miscellaneous utilities adjtimex, bbconfig, crond, crontab, dc, eject, last, less hdparm, makedevs, mountpoint, mt, nmeter, raidautorun readahead, runlevel, rx, strings, setsid, taskset, time, watchdog • networking utilities arp, arping, dnssd, ether-wake, fakeidnted, ftpget, ftpput hostname, httpd, ifconfig, ifupdown, inetd, ipaddr, iplink iproute, iptunnel, iprule, ipcalc, nameif, nc, netstat, nslookup ping, route, telnet, telnetd, tftp, traceroute, vconfig, wget zcp • process utilities
--	--

	<p>free, fuser, kill, killall, killall5, pidof, ps, renice, bb_sysctl, top, uptime</p> <ul style="list-style-type: none"> • shells ash • runit utilities chpst, setuidgid, envuidgid, envdir softlimit
mtd-utils	1.00
bash	2.05b
xfs-progs	2.5.6
e2fsprogs	1.27
samba	3.0.21c
libtermcap	2.0.8
libncurses	5.2
sl	--

7. Setup Procedure

7.1. Flow of Operation for First Startup


After purchasing your Kurobox and switching the power on, it will start up in the following condition.

uImage	/dev/mtdblock1(NAND device)
rootfs	/dev/mtdblock2 (NAND device)
smb shared directory	mtd_device (/dev/mtdblock3 mountpoint: /mnt/mtd) share(/dev/sda mountpoint /mnt/disk1)
telnet	Connection possible


However, at this point only mtd_device is actually accessible.

The following operation is required to make the share directory useable.

1. Connect either the internal disk or usb disk, and boot up.
2. After boot-up is completed, press and hold the initialization switch on the back of the Kurobox to format the internal disk or usb disk, and mount in xfs.
3. After performing the operation in 2, it is possible to access share.



7.2 Finding the IP Address



1. Type [\\KUROBOX-PRO] into the address bar of explorer, and check that you can access it.
2. After confirming that connections are possible, enter [Start] → [Run] → [cmd], and after the command prompt has started, check the IP address using the [ping KUROBOX-PRO] command. The underlined section is the KUROBOX-PRO IP address.

```

C:\WINDOWS\system32\cmd.exe
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\y-hara>ping KUROBOX-PRO

Pinging KUROBOX-PRO [172.16.37.48] with 32 bytes of data:

Reply from 172.16.37.48: bytes=32 time<1ms TTL=64
Reply from 172.16.37.48: bytes=32 time<1ms TTL=64
Reply from 172.16.37.48: bytes=32 time<1ms TTL=64
Reply from 172.16.37.48: bytes=32 time<1ms TTL=64

Ping statistics for 172.16.37.48:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 0ms, Average = 0ms

C:\Documents and Settings\y-hara>

```

7.3. Setting the Shared Folder

1. Enter a URL as shown below to open the KUROBOX-PRO web setting page. (In the example, the KUROBOX-PRO IP address is 192.168.11.150)




2. A basic authorization dialog box like the one below is displayed. Enter your username and password.

User name	Default password
root	kuroadmin



3. A swat page like the one shown below is displayed, and shared folders can be added etc.



8. Others

8.1. Factory Settings (Not Setup Condition)

Item	Value
Firmware mode	Normal startup
root password	kuroadmin
KURO-BOX name	KUROBOX-PRO
Time	Not set
IP address/subnet mask	Obtained from the DHCP server (If cannot be obtained, 192.168.11.150)
Ethernet frame size (MTU size)	1518 bytes (1500 bytes)
Smb shared functions	Use
TELNET server functions	Use

8.2. Error Code List

Error code	Details of error
E00	MPU malfunction Main MPU not responding
E01	DRAM DATA LINE error
E02	DRAM ADDRESS LINE error
E04	Kernel expansion failed
E05	Watchdog Timer
E06	Kernel image read failed (initrd does not exist on the HDD)
E07	Could not confirm connection of HDD

* E00 is expressed by all the lights switching off. LEDs are off, and only an alarm sounds

Appendix

Appendix A: Example of u-boot environment variable settings

A.1. Boot settings when ulmage(nand /dev/mtdblock1), rootfs(nand /dev/mtdblock2)

uImage	/dev/mtdblock1 (0x00020000~0x00400000) 4MB arrangement excluding head 128KB
initrd	-----(Not use)
rootfs	/dev/mtdblock2

u-boot environment variable settings

```

setenv default_kernel_addr 0x00100000
setenv bootargs_base console=ttyS0,115200
setenv bootargs_root root=/dev/mtdblock2 rw
setenv bootargs $(bootargs_base) $(bootargs_root) $(buffalo_ver)
setenv uImage_block 0
setenv uImage_offset 0x00020000
setenv bootcmd 'nboot $(default_kernel_addr) $(uImage_block) $(uImage_offset); bootm
$(default_kernel_addr)'

```

A.2. Boot settings when ulmage(nand /dev/mtdblock1), rootfs(/dev/sda2)

uImage	/dev/mtdblock1 (0x00020000~0x00400000) 4MB arrangement excluding head 128KB
initrd	-----(Not use)
rootfs	/dev/sda2

u-boot environment settings

```

setenv default_kernel_addr 0x00100000
setenv bootargs_base console=ttyS0,115200
setenv bootargs_root root=/dev/sda2 rw
setenv bootargs $(bootargs_base) $(bootargs_root) $(buffalo_ver)
setenv uImage_block 0
setenv uImage_offset 0x00020000
setenv bootcmd 'nboot $(default_kernel_addr) $(uImage_block) $(uImage_offset); bootm
$(default_kernel_addr)'

```

A.3. Boot settings when ulmage(/dev/sda1), rootfs(/dev/sda2)

uImage	/dev/sda1
initrd	----- (Not use)
rootfs	/dev/sda2
Notes	/dev/sdal is formatted in ext2, and uImage.buffalo is stored.

u-boot environment settings

```
setenv default_kernel_addr 0x00100000
setenv bootargs_base console=ttyS0,115200
setenv bootargs_root root=/dev/sda2 rw
setenv bootargs $(bootargs_base) $(bootargs_root) $(buffalo_ver)
setenv bootcmd 'ext2load ide 0:1 $(default_kernel_addr)/$(kernel); bootm $(default_kernel_addr)'
```

A.4. Boot settings when ulmage(tftp load), rootfs(nand /dev/mtdblock2)

uImage	Load from tftp
initrd	----- (Not use)
rootfs	/dev/mtdblock2
tftpserver	(e.g.) 192.168.11.100
KUROBOX-PRO	(e.g.) 192.168.11.150
Notes	uImage.buffalo exists in the tftp root directory of tftpserver.

u-boot environment variable settings

```
setenv default_kernel_addr 0x00100000
setenv bootargs_base console=ttyS0,115200
setenv bootargs_root root=/dev/mtdblock2 rw
setenv bootargs $(bootargs_base) $(bootargs_root) $(buffalo_ver)
setenv serverip 192.168.11.100
setenv ipaddr 192.168.11.150
setenv bootcmd 'tftp $(default_kernel_addr) $(kernel); bootm $(default_kernel_addr)'
```

A.5. Boot settings when ulmage(tftp load), initrd(tftp load)

uImage	Load from tftp
initrd	Load from tftp
rootfs	Exists in initrd
tftpserver	(e.g.) 192.168.11.100
KUROBOX-PRO	(e.g.) 192.168.11.150
Notes	<ul style="list-style-type: none"> • uImage.buffalo and initrd.buffalo exist in the tftp root directory of tftpserver. • rootfs exists in initrd. • After expanding rootfs in initrd, it is within 32MB.

u-boot environment variable settings

```
setenv default_kernel_addr 0x00100000
```

```
setenv default_initrd_addr 0x02000000
```

```
setenv bootargs_base console=ttyS0,115200
```

```
setenv bootargs_root root=/dev/mtdblock2 rw
```

```
setenv bootargs "${bootargs_base} ${bootargs_root} ${buffalo_ver}
```

```
setenv serverip 192.168.11.100
```


```
setenv ipaddr 192.168.11.150
```

```
setenv bootcmd 'tftp ${default_kernel_addr} ${kernel}; tftp ${default_initrd_addr} ${initrd}; bootm  
${default_kernel_addr} ${default_initrd_addr}'
```


Appendix B: Constructing the Development Environment

You can create the gcc environment by expanding the [development_kit\hddrootfs.tar.gz] file stored on the supplied CD-ROM. However, in order to avoid too many accesses to the NAND flash, it is recommended that you prepare the development environment on the HDD. You can prepare the development environment on the HDD by using the following procedure.

1. Copy hddrootfx.tar.gz to KUROBOX-PRO via the smb.
2. Connect to KUROBOX-PRO by telnet.




2. Connect to KUROBOX-PRO by telnet, and login as root.



3. Expand in the HDD.

The commands you will use are shown below.

```
tar -zxvf /mnt/disk1/hddrootfs.tar.gz -C /mnt/disk1
```



```

c:\ Telnet KUROBOX-PRO
BUFFALO INC. KUROBOX Series KUROBOX/PRO(KOSHO)
KUROBOX-PRO login: root
Password:


BusyBox v1.4.1 (2007-02-02 22:42:57 JST) Built-in shell (ash)
Enter 'help' for a list of built-in commands.

~ # tar -zxvf /mnt/disk1/hddrootfs.tar.gz -C /mnt/disk1

```

4. Execute the following commands, and construction of the development environment is completed if gcc and make operate.

```
chroot /mnt/disk1
```



```

c:\ Telnet 172.16.37.61
sh-3.1# gcc -v
Using built-in specs.
Target: arm-none-linux-gnueabi
Configured with: ../../tools/gcc/configure --prefix=/usr --libexecdir=/usr/lib --build=i386-redhat-linux --host=arm-none-linux-gnueabi --target=arm-none-linux-gnueabi --enable-shared --enable-threads=posix --enable-__cxa_atexit --enable-c99 --enable-long-long --enable-clocale=gnu --enable-languages=c,c++ --disable-libstdcxx-pch
Thread model: posix
gcc version 4.1.1
sh-3.1# make -v
GNU Make 3.81
Copyright (C) 2006 Free Software Foundation, Inc.
This is free software; see the source for copying conditions.
There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

This program built for arm-none-linux-gnueabi
sh-3.1#

```

Also, although operation is not guaranteed, the HDD boot environment can be created using the following procedure.

1. Connect an unformatted HDD, and boot up normally.
2. Copy the following files in development_kit of the CD-ROM to [mtd device] in the shared directory.

hddrootfs.tar.gz	hddrootfs for development environment
ChangeMeDevHDD	Purpose-displayed file for setting the HDD partition for development
ChangeMyUbootEnv	<p>Purpose-displayed file for rewriting the u-boot environment variable</p> <p>* If the u-boot environment variable is set to an invalid value, it may not be able to start up again.</p> <p>If there are no problems in the chroot environment, do not copy this file.</p>
uImage.buffalo	Kernel

3. In the above condition, press the initsw on the back of the product.
4. Infoled flashes, and formatting, expansion of the development environment, and rewriting of the u-boot environment variable are performed.

Appendix C: Kernel Compile Procedure

At present the kernel cannot be compiled on the target. Therefore, you need to install Linux onto an I386 system PC and construct a cross compile environment before building the kernel. That procedure is shown below.

C.1. Constructing a Cross Compile Environment

1. Download the cross compiler from the sites shown below, and install it on your PC-Linux.

<http://www.codesourcery.com/>

http://www.codesourcery.com/gnu_toolchains/arm/releases.html

Release Version	2005q3-2
Target Platform	ARM GNU/Linux
Host Platform	IA32 GNU/Linux

2. By expanding the downloaded binary, the environment for generating binaries for arm is prepared.

C.2. Compiling the Kernel

1. Set the path to the cross compiler.

e.g.: `mkdir /opt/arm-2005q3-2`

```
tar -jxvf arm-2005q3-2-arm-none-linux-gnueabi-i686-pc-linux-gnu.tar.bz2 \
-C /opt/arm-2005q3-2
```

If the above example is extracted, execute the following command.

```
PATH=${PATH}:/opt/arm-2005q3-2/arm-none-linux-gnueabi/bin
```

3. You can compile the kernel by extracting the kernel source included in the CD-ROM of this product and executing `make` in the top directory.
4. Execute the `make uImage` command to create a u-boot image. At that time, the `mkimage` package is required.

Appendix D: Operation check completed PCIe card

Type	Vendor	Part number
Network Card	Kuroutoshikou	GBE-PCIe